


## 17.9: Spectroscopic Properties


### IR

The carboxyl group is associated with two characteristic infrared stretching absorptions which change markedly with hydrogen bonding. The spectrum of a  $\text{CCl}_4$  solution of propionic acid (propanoic acid), shown below, is illustrative. Carboxylic acids exist predominantly as **hydrogen bonded dimers** in condensed phases. The O-H stretching absorption for such dimers is very strong and broad, extending from 2500 to 3300  $\text{cm}^{-1}$ . This absorption overlaps the sharper C-H stretching peaks, which may be seen extending beyond the O-H envelope at 2990, 2950 and 2870  $\text{cm}^{-1}$ . The smaller peaks protruding near 2655 and 2560 are characteristic of the dimer. In ether solvents a sharper hydrogen bonded monomer absorption near 3500  $\text{cm}^{-1}$  is observed, due to competition of the ether oxygen as a hydrogen bond acceptor. The carbonyl stretching frequency of the dimer is found near 1710  $\text{cm}^{-1}$ , but is increased by 25  $\text{cm}^{-1}$  or more in the monomeric state. Other characteristic stretching and bending absorptions are marked in the spectrum.




### NMR

The combination of anisotropy and electronegativity causes the O-H hydrogen in a carboxylic acid to be very deshielded.



Hydrogen environments adjacent to a carboxylic acid are shifted to the region of 2.5-3.0 ppm. Deshielding occurs due to the fact that the  $\text{sp}^2$  hybridized carbon the the carboxylic acid is more electronegative than a  $\text{sp}^3$  hybridized carbon.



## Contributors

- William Reusch, Professor Emeritus ([Michigan State U.](#)), [Virtual Textbook of Organic Chemistry](#)
- Prof. Steven Farmer ([Sonoma State University](#))

---

17.9: Spectroscopic Properties is shared under a [CC BY-NC-SA 4.0](#) license and was authored, remixed, and/or curated by LibreTexts.